





No.	Part Name
1	Motor Mount Main
2	Motor Alignment Coupler
3	Spindle Coupling
4	Rotary Table Mount Face
5	Rotary Table Spindle
6	Motor